



Installation Training & Information

ASME B31.3 installer training courses are available from Spears® at no cost. If you would like to arrange for training or have any questions about the safe installation and use of this system, contact Spears® Manufacturing Company, 15853 Olden Street, Sylmar, CA 91342 USA, Telephone (818) 364-1611.

Handling & Storage

Spears® marine products are packaged and shipped with care to avoid damage. Pipe and fittings should be stored and protected from direct exposure to sunlight. All pipe and accessories should be stored above ground and fully supported so as not to bend or excessively deflect under its own weight. Proper stacking can result in instability that may result in pipe damage or personnel injury.

Use care when transporting and storing the product to prevent damage. Piping products should not be dropped or have objects dropped on them. Do not drag pipe over articles or across the ground and do not subject pipe to external loads or over stacking. If extended storage in direct sunlight is expected, pipe should be covered with an opaque material while permitting adequate air circulation above and around the pipe as required to prevent excessive heat accumulation.

Spears® marine products should not be stored or installed close to heat-producing sources. CPVC storage should not exceed 210°F. Handling techniques for CPVC marine pipe considered acceptable at warm temperatures may be unacceptable at very cold temperatures. When handling pipe in cold weather, consideration must be given to its lower impact strength. In subfreezing temperatures, extra caution in handling must be taken to prevent impact damage. All CPVC marine pipe should be inspected for any scratches, splits or gouges before use. Damaged sections must be cut out and discarded.

Plastic Piping Tools

Basic Tools used with Plastic Piping

Use tools that have been specifically designed for use with thermoplastic pipe and fittings when installing. A variety of tools that are designed for cutting, beveling, and assembling plastic pipe and fittings, are readily available through local wholesale supply houses dealing in plastic pipe and fittings.

•**Warning** Tools normally used with metal piping systems, such as hacksaws, water pump pliers, pipe wrenches, etc., can cause damage to plastic pipe and fittings. Visible and hidden fractures, scoring or gouging of material, and over tightening of plastic threaded connections are some of the common problems resulting from the use of incorrect tools and procedures.

Pipe Cutters

Pipe must be square-cut to allow for the proper joining of pipe end and the fitting socket bottom. Wheel type pipe cutters designed for plastic pipe provides easy and clean cuts on smaller pipe sizes. Care should be used with similar ratchet-type cutters to avoid damage to pipe. A slightly raised edge left on the outside of the pipe end after cutting with either device must be removed.

Pipe Cutters for Large Diameter Pipe

Blade cutters made for use with large diameter plastic pipe are easy to adjust and operate for square, burr-less cuts. Blades with carbide edges will provide longer life. With one style blade cutter, pipe ends may also be beveled for solvent joints while being cut by using an optional bevel tool in place of one cutter blade.

Hand Saws

A miter box or similar guide can be used with a fine-toothed saw blade (16 to 18 teeth per inch) having little or no set (maximum 0.025 inch).

Power Saws

Power saws are quite useful in operations where a large quantity of pipe is being cut. Blades designed for plastic pipe **MUST** be used. A cutting speed of 6,000 RPM, using ordinary hand pressure is recommended.

Pipe Beveling Tools

Power beveling tools, as well as hand beveling tools designed for use with plastic pipe are available. Pipe ends must be beveled (chamfered) to allow easy insertion of the pipe into the fitting and to help spread solvent cement and to prevent scraping cement from the inside of the fitting socket. A recommended bevel of 1/16" to 3/32" at a 10° to 15° angle can be achieved using a plastic pipe beveling tool, but can also be accomplished using a file designed for use on plastic.

Deburring Tools

Special plastic pipe deburring tools remove burrs from pipe ends quickly and efficiently. All burrs must be removed from the inside, as well as the outside, of the pipe ends to properly spread solvent cement when joining pipe and fitting.

Strap Wrenches

Strap wrenches with nylon straps treated for slip resistance and designed for use with plastic pipe provide gripping power for turning without scratching or deforming the pipe.

Chain Vises

Chain vises can be used to hold pipe. Vises made with jaws engineered for use with plastic pipe provide holding power without damage to the pipe.

Pullers & Joining Devices

Pipe and fitting pullers are available for joining large diameter plastic pipe and fittings. These tools are designed to allow the pipe to be inserted to the proper insertion depth, maintain proper alignment during assembly, and hold freshly solvent-cemented connections to prevent the fitting from backing-off until the initial set time is achieved.

Joining Methods - Solvent Cement Welding

Solvent cement welding is the most widely used joining method for PVC and CPVC pipe and fittings. Other methods such as threads, flanges and groove adapters can also be used. These are specifically useful where it is anticipated that the joint will have to be disassembled in the future.

Solvent Cement Safety Precautions

Solvent cement products are flammable and contain chemical solvents. Appropriate safety precautions must be taken BEFORE APPLYING PRIMER AND CEMENT. Read the cement can label!

•CAUTION

*Virtually all solvent cements and primers for plastic pipe are flammable and should not be used or stored near heat, spark or open flames. Do not smoke during use. Eliminate all ignition sources. Primer should be stored in closed containers in the shade at temperatures between 40°F and 110°F; CPVC cement at temperatures between 40°F and 90°F. Use of a can with applicator attached to its lid is recommended. **Verify expiration dates stamped on cements and primers prior to use.***

Avoid breathing vapors. They should be used only with adequate ventilation. Explosion-proof general mechanical ventilation is recommended. In confined or partially enclosed areas, a ventilating device should be used. Containers should be kept tightly closed when not in use, and covered as much as possible when in use.

Avoid contact with skin and eyes. May be absorbed through the skin; wearing PVA coated protective gloves and an impervious apron are recommended. May cause eye injury. Use eye protection and avoid eye contact. In case of contact, flush with plenty of water for 15 minutes. If irritation persists, get medical attention. If swallowed, call a physician immediately and follow precautionary statement given on side panel of cement container. Keep out of reach of children.

Refer to Solvent Cement Safety Data Sheet (SDS)

Use Caution with Welding Torches or other equipment where sparks might be involved at construction sites where plastic pipe has recently been solvent welded. Flammable vapors from cemented joints can stay within a piping system for some time. In all cases, lines should be flushed and purged to remove solvent vapors before welding.

Use Caution with Calcium Hypochlorite. Do not use a dry granular calcium hypochlorite as a disinfecting material for water purification in potable water piping systems. Granules or pellets of calcium hypochlorite (including their vapors) may react violently with solvent cements and primers if a water solution is not used. Chlorinated water solutions are nonvolatile and may be pumped into the piping system. Dry granular calcium hypochlorite should not be stored or used near solvent cements or primers.

Solvent Cement and Primer Spills

Protect work areas prior to starting by using drop cloths in the event of a spill. Accidental spills should be wiped up immediately before the cement sets. Cement and/or primer spills can cause irreparable damage depending on the type of surface affected. Consult the manufacturer of the affected surface for possible suggestions.

Basic Solvent Cement Joints

The following is a general description of basic techniques used to make solvent cement joints. Adjustments will need to be made to method and tools used according to size of piping, but the same principles apply. Additional guidance can be found in ASTM D 2855, Standard Practice for Making Solvent-Cemented Joints with Poly (Vinyl Chloride) (PVC) Pipe and Fittings. **Important:** Installers should verify that they can make satisfactory joints under varying conditions and should receive training in installation and safety procedures.

Spears® offers Bonder Qualification Training (ASME B31.3) as required by the U.S. Coast Guard and Classification Societies. Contact Spears® for more information: (818) 364-1611.

To consistently make good joints in PVC and CPVC piping products, the following should be carefully understood:

1. The joining surfaces of pipe and fitting must be softened and made semi-fluid.
2. Sufficient cement must be applied to fill the gap between pipe and fitting.
3. Assembly of pipe and fittings must be made while the surfaces are still wet and fluid.
4. Joint strength develops as the cement dries (cures). In the tight part of the joint (interference area) the surfaces will fuse together; in the loose part the cement will bond to both surfaces.

Cutting the Pipe

CPVC pipe can be cut easily with a ratchet cutter, wheel-type plastic pipe cutter (NOTE: be sure to remove any raised ridge produced by wheel cutters), a power saw, or any other fine-tooth saw. It is important that the cutting tools being used are designed for plastic pipe. To ensure that the pipe is cut square, use a miter box when cutting with a saw. Cutting pipe as square as possible provides the maximum bonding surface area.



Be careful not to split the tube if using a ratchet-type cutter, especially in temperatures below 50°F. If any damage or cracking is evident, cut off at least 2" of the pipe beyond any visible crack.


Deburring & Beveling

Burrs and filings can prevent contact between the tube and the fitting during assembly and must be removed from the outside and the inside of the pipe. A deburring/chamfering tool (or file) is suitable for this purpose:



Burrs Being Removed from Outside & Inside

A slight bevel (chamfer) must be placed at the outside end of the pipe to ease the entry of the tube into the socket and minimize the chance of cement being wiped off the fitting:



Bevel Outside End

Fitting & Joining Preparation

1. Using a clean, dry rag, wipe any loose dirt and moisture from the fitting's socket and pipe end. Moisture can slow the cure time, and at this stage of assembly, excessive moisture can reduce joint strength.
2. Check the dry fit of the pipe and fitting. The pipe should enter the fitting's socket easily 1/3 - 2/3 of the way (interference fit), or at least have interference between pipe and fitting bottom (net fit). **DO NOT** use any components that appear irregular or do not fit properly. Contact Spears® regarding any questions about usability.
3. Measure socket depth and mark on pipe for reference during cement application.
4. It is advisable to additionally mark pipe and fitting for alignment orientation position, especially with larger fittings.



Solvent Cementing Assembly

Verify the expiration date located on the solvent cement can. The cement can be used for a period of 2 years from the date stamped on the can. When cementing pipe and fittings in extremely cold temperatures, make sure the cement has not "JELLED." Jelled or expired cement must be discarded in an environmentally friendly fashion, in accordance with local regulations. To prolong the life of solvent cement, keep the containers tightly closed when not in use, and cover the container as much as possible during use. If an unopened solvent cement container is subjected to freezing temperatures, the cement may become extremely thick. Place the closed container in a room temperature area where, after a short time period, the cement will return to a usable condition. **DO NOT** attempt to heat solvent cement. The cement must be applied when the pipe and fittings are clean and free from any moisture and debris.

Primer Use - Softening of pipe and fitting joining surfaces can be achieved by the cement itself or by using a suitable primer. A primer will usually penetrate and soften the surfaces more quickly than the cement alone. The primer can be used for a period of 3 years from the date stamped on the can.

Apply Primer - USING AN APPLICATOR THAT IS AT LEAST 1/2 THE SIZE OF THE PIPE DIAMETER, vigorously scrub joining surface of fitting, of pipe and then again of fitting. Work quickly to apply 2-3 coats in this manner. SOLVENT CEMENT SHOULD THEN BE APPLIED WHILE PRIMER IS STILL WET.

Apply Solvent Cement - USING AN APPLICATOR THAT IS AT LEAST 1/2 THE SIZE OF THE PIPE DIAMETER, WORK THE CEMENT INTO THE JOINING SURFACES USING A CONTINUOUS, CIRCULAR MOTION.


Use sufficient cement, but avoid puddling the cement on or within the fitting and pipe. Puddled cement causes excess softening and damage to the CPVC material. If interference fit was at the bottom of the socket, use extra cement and make a 2nd application to pipe. **WORK QUICKLY SO THAT PIPE AND FITTING CAN BE JOINED WHILE CEMENT IS STILL WET.**

Apply the cement in the sequence pictured below:



1. Apply a coat to the pipe to depth of fitting socket

Work the cement into the joining surfaces using a continuous, circular motion.




2. Apply a medium coat to the fitting socket

Avoid puddling the cement in the sockets and avoid getting cement in other sockets or threaded connections.

3. Apply a second coat to the pipe end for sizes 1-1/4 inch and larger joints, or if interference fit was at socket bottom during dry-fit.

Assemble Joint

Immediately insert pipe into the fitting socket while rotating the pipe 1/4 turn. Align the fitting in the proper orientation at this time. Make sure the pipe bottoms out at the fitting's stop. Hold the assembly for at least 30 seconds to ensure initial bonding. Tapered pipe sockets can result in pipe backing out of the joint if not held under constant pressure. A bead of cement must be present around the pipe and fitting juncture. If this bead is not continuous around the socket's shoulder, insufficient cement was applied and the joint must be disassembled or cut out and replaced.



Any cement, in excess of the bead, can be wiped off with a dry, clean rag.

Set and Cure Times

SET TIME: The initial set time is the recommended waiting period before handling newly assembled joints. After initial set, the joints will withstand the stresses of normal installation. However, a badly misaligned installation will cause excessive stresses in the joint, pipe and fittings.

CURE TIME: The cure time is the recommended waiting period before pressurizing newly assembled joints.

The following basic guidelines should be used:

- The set and cure times for solvent cement depend on pipe size, temperature, relative humidity, and tightness of fit. Drying time is faster for drier environments, smaller pipe sizes, high temperatures, and tighter fits.
- Special care must be taken when assembling products in low temperatures (below 40°F) or high temperatures (above 80°F).
- Extra set and handling times must be allowed in colder temperatures. When cementing pipe and fittings in cold temperatures, make sure the cement has not "JELLED." Jelled cement must be discarded.
- In higher temperatures, make sure both surfaces to be joined are still wet with cement during assembly.
- The assembly must be allowed an initial set, without any stress on the joint
- Following the initial set period, the assembly can be handled carefully by avoiding stress on the joint.

Average Set Times

Temp. Range	Pipe Sizes 1/2"- 1-1/4"	Pipe Sizes 1-1/2"- 2"	Pipe Sizes 2-1/2"- 8"	Pipe Sizes 10"- 12"
60° - 100°F	2 Min.	5 Min.	30 Min.	2 Hrs.
40° - 60°F	5 Min.	10 Min.	2 Hrs.	8 Hrs.
0° - 40°F	10 Min.	15 Min.	12 Hrs.	24 Hrs.



Average Cure Times

Relative Humidity 60% or Less*	Pipe Sizes 1/2" - 1-1/4"		Pipe Sizes 1-1/2" - 2"		Pipe Sizes 2-1/2" - 8"		Pipe Sizes 10" - 12"
	Up to 160 psi	Above 160 to 370 psi	Up to 160 psi	Above 160 to 315 psi	Up to 160 psi	Above 160 to 315 psi	Up to 100 psi
60° - 100°F	15 Min.	6 Hrs.	30 Min.	12 Hrs.	1-1/2 Hrs.	24 Hrs.	48 Hrs.
40° - 60°F	20 Min.	12 Hrs.	45 Min.	24 Hrs.	4 Hrs.	48 Hrs.	96 Hrs.
0° - 40°F	30 Min.	48 Hrs.	1 Hr.	96 Hrs.	72 Hrs.	8 Days	8 days

•NOTE In damp or humid weather allow 50% more cure time. The cure schedules shown are suggested as guides only. They are based on laboratory test data, and should not be taken to be the recommendations of all cement manufacturers. Individual solvent cement manufacturer's recommendations for the particular cement being used should be followed.

Special Considerations for Working with Solvent Cement Welding

Handling of Cement

Keep Marine-24 cement containers covered while not in use. Marine-24 Cement with the lid left off can become thick and viscous, or gel like. This condition is typically a result of tetrahydrofuran (THF) solvent evaporation and the cement is useless. Do not try to restore the Marine-24 cement by stirring in a thinner. Smaller containers of Marine-24 cement are recommended to be used, especially in warm or hot weather. Prior to opening cans of Marine-24 cement, shake vigorously to properly mix resin and solvents. Solvents contained in Marine-24 cement are highly flammable and should not be used near an open flame. The area in which the Marine-24 cement is being used should be well ventilated, and prolonged breathing of the fumes should be avoided, as well as contact with the skin or eyes. Verify the expiration dates stamped on the Marine-24 cement and primers prior to use.

CEMENT AND PRIMER SHELF LIFE

Spears® Products	Shelf Life	Spears® Products	Shelf Life
Primers / Cleaners	3 years	CPVC Solvent Cement	2 years

Hot Weather Use

Problems can be avoided when solvent cementing in 95°F or higher temperatures by taking a few special precautions. Solvent cements evaporate faster at elevated temperatures and can dry out prematurely. This is especially true when there is a hot wind blowing. Dry cement on pipe or fitting socket prior to assembly will not bond. If the pipe has been in direct sunlight for any length of time, surface temperatures may be 20°F to 30°F above air temperature. Solvents attack these hot surfaces faster, deeper and dry out quicker. As a result, it is very important to avoid puddling inside sockets, assemble immediately while wet and to wipe off excess cement at the joint exterior.

Tips for Solvent Cementing in High Temperatures:

1. Store solvent cements in a cool or shaded area prior to use.
2. If possible, store the fittings and pipe, or at least the ends to be solvent welded, in a shady area before cementing.
3. Cool surfaces to be joined by wiping with a damp rag. HOWEVER, be sure that surfaces are dry prior to applying solvent cement.
4. Try to do the solvent cementing in cooler morning hours.
5. Make sure that both surfaces to be joined are still wet with cement when putting them together.

Cold Weather Use

Marine-24 solvent cement and PRIM21-70 primers have excellent cold weather stability and are formulated to have well balanced drying characteristics even in subfreezing temperatures. Good solvent cemented joints can be made in very cold conditions provided proper care and a little common sense are used. In cold weather, solvents penetrate and soften surfaces more slowly than in warm weather. The plastic is also more resistant to solvent penetration, therefore, it becomes more important to pre-soften surfaces. A longer cure time is necessary due to slower evaporation.

Tips for Solvent Cementing in Cold Temperatures:

1. Prefabricate as much of the system as possible in a heated work area.
2. Store cements in a warmer area when not in use and make sure they remain fluid.
3. Take special care to remove moisture, including ice and snow.
4. Use special care to ensure joining surfaces are adequately softened; more than one application may be necessary.
5. Allow a longer cure period before the system is used.

Effects of Tolerances and Fits

CPVC marine pipe and fittings are manufactured to applicable ASTM Standards to produce an interference fit when assembled. However, minimum and maximum allowable tolerances permitted for pipe and fitting can result in variations. For example, fitting with the maximum diameter and the pipe with the minimum diameter, may result in a loose fit. Applying two coats of solvent cement will help assure a good joint. Conversely, if the pipe diameter is on the maximum side and the fitting on the minimum side, the interference may be too great and sanding of the pipe O.D. may be necessary to permit entrance.

Always check dry fits prior to making a joint. If fit is loose, multiple coats and use of an extra heavy bodied cement may be required. Mating components should be checked to assure that tolerances and engagements are compatible (see preceding Basic Solvent Cement Joints instructions). Inspect all pipe and fittings for damage or irregularities. Do not use any components that appear irregular or do not fit properly. Contact the appropriate manufacturer of the product in question to determine usability.



Large Diameter Pipe

Basic Solvent Cement Joint instructions apply to all sizes of pipe, but when making joints larger than 4", the use of two persons is recommended to properly apply cement and immediately assemble the joint while the cemented surfaces are still wet. Alignment of large diameter pipe and fittings during joining is critical since there is a greater potential for movement in the upper portion of a tapered socket that can result in misalignment. Special tools are commercially available for joining large diameter pipe.

Be sure to use an appropriate size roller applicator with large diameter pipe, along with Marine-24 CPVC heavy bodied cement. Marine-24 cement has increased gap filling capability and allow somewhat longer assembly time. However, applications of heavy coats of solvent cement and speed in making the joint is important. Under a damp or wet condition, solvent cement may absorb some moisture. Excessive moisture can slow down the cure and reduce joint strength. Spears® Marine-24 heavy body cement is excellent for joining large diameter pipe.

Estimated Quantities of Solvent Cement

A variety of conditions can affect the amount of solvent cement required for making reliable joints. These include pipe size, tolerances, socket depths as well as installation conditions and type of cement used. Fitting sockets are tapered for proper assembly, which produces a slight gap at the socket entrance when installed with pipe. It is best to use liberal amounts of solvent cement since insufficient cement use is one of the most common reasons for joint failure. The following information on cement usage is a recommendation only and other factors or unanticipated conditions may be encountered. Quantities are based on use with average socket lengths of Spears® molded and fabricated fittings.

Standard Pipe Joints

Fitting Size (in.)	Joints per Quart	Joints per Gallon
1/2	300	1200
3/4	200	800
1	125	500
1-1/4	140	560
1-1/2	90	360
2	60	240
2-1/2	50	200
3	40	160
4	30	120
6	10	40
8	5	20
10	2-3	4-6
12	1-2	2-4

Supplemental Information on Solvent Cementing

Applicators

A wide variety of daubers, brushes, and rollers are available. For proper solvent cement welding of pipe and fittings, the cement applicator must be no less than half the size of the pipe. Sufficient cement cannot be applied using daubers attached to the cement can lid on large diameter products (> 3" dia.) The following chart shows a variety of Spears® applicator sizes for use on different pipe diameters.

SPEARS® APPLICATOR SELECTION GUIDE

For proper solvent cement welding of pipe and fittings, the cement applicator must be no less than half the size of the pipe

DAUBERS	Pipe Diameters					
	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"
3/8" Dauber	•	•				
1/2" Dauber		•	•			
3/4" Dauber				•	•	
1-1/4" Dauber						•
ROLLERS & SWABS		SIZE		FOR PIPE DIAMETERS		
3020		3" Roller		3" - 6"		
6020		4" Roller		3" - 8"		
7020		7" Roller		6" +		
5520		4" Roller		6" +		
6520		6" Roller		6" +		
4020		4" Swab		6" +		
5020		4" Swab		3" - 8"		
4520		4" Swab		6" +		

Cleaners

Cleaners can be used to remove dirt, oil and grease from the bonding surfaces of CPVC pipe and fittings. Use of a cleaner is recommended before priming of pipe and fittings.

Primers

The use of Primer is necessary to penetrate and dissolve the surface of the pipe and fitting prior to the application of cement. Primer must be applied to both the pipe and fittings. Apply multiple coats of primer to the fitting socket and to the outside of the pipe ensuring that the entire surface is wet. Solvent cement must be applied immediately after primer while the surfaces are still tacky.

Solvent Cements

Solvent cements are typically formulated using tetrahydrofuran (THF). When properly applied, this solvent dissolves the mating surfaces of the pipe and fittings. Cyclohexanone is a typical retardant used to slow the rate of solvent evaporation. Immediate joining of the wet mating surfaces in one minute or less is essential to eliminate dry spots that will not bond. The bond interface is strongest at the area of interference fit where the softened semi-fluid surfaces of the pipe and fitting chemically fuse. Plastic resin fillers (dissolved CPVC) in the cement fill the gaps between pipe and fitting.



Joining Method - Threaded Connections

Threaded connections require the application of a thread sealant that is compatible with CPVC material. Spears® recommends the use of Spears® Blue 75™ Thread Sealant.

CAUTION - Use only thread sealants recommended for CPVC plastic. Other joint compounds or pastes may contain substances that could cause stress cracks in CPVC materials.

Apply sealant to the male threads only. Make sure all threads are covered. **DO NOT** clog the waterway with excess sealant. If PTFE tape must be used, Spears® recommends a thickness of at least .0035" that meets or exceeds military specification, A-A-58092 (formerly MIL-T-27730A). **DO NOT** use a combination of tape and thread paste on the same joint. Apply PTFE tape in the direction of the threads by starting with the first full thread and continuing over the entire thread length. Make sure all threads are covered. Generally, 2 - 3 wraps are sufficient to produce a watertight connection

DO NOT over-torque any threaded connections. Generally, one to two turns beyond finger-tight are required for a threaded connection. Use a smooth-jawed wrench or strap wrench when installing threaded connections.

Threading Pipe

CPVC marine schedule 80 pipe can be threaded using either standard hand pipe stocks or power-operated equipment. Since rigid CPVC plastic pipe has the same outside diameter as standard steel pipe in comparable sizes, standard steel pipe taps and dies can be used. A cut thread or deep scratch results in a stress concentration point. As a result, only Schedule 80 pipe should be threaded. A 50% pressure de-rating is applied to threaded pipe to compensate for this. **DO NOT** thread Schedule 40 pipe. For optimum results in threading, use new taps and dies; but in any case, they should be cleaned and sharpened and in good condition. Power threading machines should be fitted with dies having a 5° negative front rake and ground especially for this type of pipe; tapered guide sleeves are not required. For hand stocks the dies should have a negative front rake of 5° to 10°. Dies which have been designed for use on brass or copper pipes may be used successfully. Carboly dies give longer service. (Taps should be ground with a 0° to 10° negative rake, depending upon the size and pitch of the thread. Die chasers should have a 33° chamfer on the lead; a 10° front or negative rake; and a 5° rake on the back or relief edge).


Self-opening die heads and collapsible taps, power threading machines and a slight chamfer to lead the tap or dies will speed production; however, taps and dies should not be driven at high speeds or with heavy pressure.

A tapered plug should be inserted into the pipe when threading, to hold the pipe round and to prevent the die from distorting and digging into the pipe wall. This ensures uniform thread depth all the way around. Pipe for threading should be held in a suitable pipe vise, but saw-tooth jaws should not be used. Flanges and close nipples should be threaded in jigs or tapping fixtures. To prevent crushing or scoring the pipe, some type of protective wrap, such as canvas, emery paper, or a light metal sleeve should be used; rounding of chuck jaws will also be helpful. Rigid CPVC plastic pipe should be threaded without use of lubricants. Standard cutting oils can cause stress cracking in plastics and should not be used. Water-soluble oil or plain water is recommended. Degreasing with any solvents is not recommended, nor should solvents be used in any cleanup. Always clear cuttings from the die.

DO NOT OVER THREAD - To obtain a tight, leak proof joint, the thread dimensions shown in the table should be used. If pipe is over threaded, fittings cannot be run on far enough to make a tight seal.

American National Standards Institute Code B1.20.1 covers dimensions and tolerances for tapered pipe threads. **Only Schedule 80 pipe should be threaded.**

Angle between sides of thread is 60 degrees. Taper of thread, on diameter, is 3/4 inch per foot. The basic thread depth is 0.8 x pitch of thread and the crest and root are truncated an amount equal to 0.033 x pitch, excepting 8 threads per inch which have a basic depth of 0.778 x pitch and are truncated 0.045 x pitch at the crest and 0.033 x pitch at the root.



PIPE THREADS

Nominal Size (in.) (Max.) (In.)	Outside Diameter (in.) D	Number of Threads Per Inch	Normal Engagement By Hand (in.) C	Length of Effective Thread (in.) A	Total Length: End of pipe to vanish point (in.) B	Pitch Diameter at end of Internal Thread (in.) E	Depth of Thread (Max.) (in.)
1/2	0.840	14	0.320	0.5337	0.7815	0.77843	0.05714
3/4	1.050	14	0.339	0.5457	0.7935	0.98887	0.05714
1	1.315	11-1/2	0.400	0.6828	0.9845	1.23863	0.06957
1-1/4	1.660	11-1/2	0.420	0.7068	1.0085	1.58338	0.06957
1-1/2	1.900	11-1/2	0.420	0.7235	1.0252	1.82234	0.06957
2	2.375	11-1/2	0.436	0.7565	1.0582	2.29627	0.06957
2-1/2	2.875	8	0.682	1.1375	1.5712	2.76216	0.10000
3	3.500	8	0.766	1.2000	1.6337	3.38850	0.10000
4	4.500	8	0.844	1.3000	1.7337	4.38713	0.10000
6	6.625	8	0.958	1.5125	1.9462	6.50597	0.10000



Joining Method - Flanged Connections

PVC and CPVC flanges are available in several designs, including solid one-piece flanges, two-piece Van Stone style flanges featuring a movable ring for bolt alignment, and blind flanges for capping off a piping run. Marine flanges are available in socket, spigot and threaded configurations and are coupling devices designed for joining IPS (Iron Pipe Size) plastic piping systems where frequent disassembly may be required. Flanges can be used as a transitional fitting for joining plastic to metal piping systems, and for connection to other flanged type valves and equipment. A flat gasket is used between flanges to form a water-tight seal. Proper gasket material should be selected for fluid compatibility. Most plastic flanges carry a maximum working pressure rating of 150 psi non-shock for water at 73° F (23° C). Pressure ratings may vary according to size and flange construction. Consult flange manufacturer.

Gaskets

Select appropriate size and bolt pattern gasket. Full faced, 1/8" thick elastomer flat gaskets with a Shore "A" Durometer of approximately 70 (±5) are recommended. A full-face flat gasket should cover the entire flange face but not obstruct the waterway. Verify that the gasket material is chemically compatible for use with the application fluid conveyed through the system.

Low Torque Double Convex Design Full Face Gaskets

Low torque-style gaskets require up to 50% less torque to achieve a leak-free seal. When using this type of gasket in combination with Spears® flanges be sure to follow the torque recommendations from the low torque gasket manufacturer. Over-torquing a low torque gasket may cause damage to the flange.

DO NOT USE: Spiral wound, ring, kammprofile, corrugated metal gaskets, non-asbestos or cork gaskets.

Bolt Patterns & Fastener Selection

Most PVC and CPVC flanges are produced with ANSI B16.5 bolt patterns for Class 125/150 flanges. Optional Class 300 bolt patterns (NOT a 300psi rating), certain ANSI/Metric dual pattern flanges, and metric bolt patterns can be produced. Proper bolt size, number and length should be selected for the specific flanges and equipment being assembled. Bolt length requirements will vary according to the flange or equipment manufacturer. Spears® offers bolt packs (HK series) for use with Spears® flange to flange assemblies.

Bolts: To ensure minimal friction use a zinc-plated grade 5 bolt or stud of suitable length in accordance with ASME B18.2.1 to accommodate (2) flange thicknesses, (2) washers and (1) 1/8" full face gasket thickness.

Nuts: Use grade 5 zinc-plated hex nuts in accordance with ASME B18.2.2. Orient nut so flat side contacts flange surface.

Washers: Always use (2) wide flat washers for each bolt, one under the bolt head and one under the nut. Use flat, zinc-plated steel (Plate type) grade 5 washers in accordance with ASME B18.21.1 (Do not use thin "fender" washers).

Important: Stainless steel fasteners can be used. Be sure to use a compatible anti-seize lubricant to eliminate galling.

Bolt Preparation & Torque

Threads should be cleaned and well lubricated. Apply a liberal amount of a chemically compatible copper-graphite anti-seize bolt lubricant to each bolt thread. Use a lubricant with a K factor (nut factor) of 0.15. Adequate application of thread lubricant is indicated by lubricant extrusion from the threaded joint as the nut is tightened. (**WARNING:** Use only bolt lubricants compatible with PVC or CPVC material).


Hand tighten all nuts until they are snug prior to torquing flange bolts. Using a calibrated torque wrench accurate to within ± 1ft-lb. tighten each bolt in approximately 5 ft-lb. increments using a 180° opposing sequence. Follow the

numbers sequence engraved next to each Spears® flange bolt hole or consult **Torque Sequence - Table 1** information. Actual field conditions may require variations in these recommendations. **UNNECESSARY OVER-TORQUING WILL DAMAGE THE FLANGE.** Torque should always be applied in approximately 5 ft-lb. increments using a 180° opposing sequence.

Flange Make-up

Follow proper solvent cementing and/or threaded component procedures as applicable to join the flange to the pipe. Once a flange is joined to pipe, the method for joining two flanges is as follows:

1. Piping runs joined to the flanges must be installed in a straight-line position to the flange to avoid stress at the flange due to misalignment. Piping must also be secured and supported to prevent lateral movement which can create stress and damage the flange.



Proper Alignment

Improper Alignment

2. With full face gasket in place, align the bolt holes of the mating flanges by rotating the ring into position with a Van Stone style flange or by rotating the pipe assembly with a one-piece flange installed.
3. Insert all bolts, washers (two standard flat washers per bolt), and nuts.
4. Make sure the faces of the mating surfaces are flush against gasket prior to bolting down the flanges.
5. Tighten all nuts by hand until they are snug. Establish uniform pressure over the flange face by tightening the bolts in 5 ft.-lb. increments according to the torque values shown in the following table using a 180° opposing sequence. Make sure that there are at least two (2) exposed threads beyond the nut upon final tightening.

NOTE: Thermoplastic materials relax over time. Re-torquing may be necessary 24 hours after initial tightening.

Unsupported Flange Connections to other Equipment

For flange connections assembled to raised face flanges, appurtenances and/or equipment such as flow meters, expansion joints or wafer style butterfly valves where the flange face is not supported in direct contact with the mating flange, care must be taken to avoid "bending" the flange. Do not use bolts to bring together improperly mated flanges. Listed bolt torque may cause deformation or cracking from these types of connections since the flange is not fully supported by the mating flange. For unsupported flange connections start with approximately two-thirds (2/3) of the listed maximum torque and increase as necessary to make the system leak-free after pressure testing.

Important: Be sure to contact the appurtenance or equipment manufacturer for recommendations regarding use of plastic flanges with their products.



Recommended Flange Bolt Torque for Plastic Flanges


Flange Size (in.)	No. of Bolt Holes	Bolt Dia. (in.) ¹	Min. Bolt Length (in.) ¹	Torque ft.-lb. ²
1/2	4	1/2	2	12
3/4	4	1/2	2	12
1	4	1/2	2-1/4	12
1-1/4	4	1/2	2-1/4	12
1-1/2	4	1/2	2-1/2	12
2	4	5/8	3	25
2-1/2	4	5/8	3-1/4	25
3	4	5/8	3-1/4	25
4	8	5/8	3-1/2	25
6	8	3/4	4	40
8	8	3/4	4-1/2	40
10	12	7/8	5	64
12	12	7/8	5	95

Note:

- Minimum bolt length is based on connecting two (2) Spears® flanges, two (2) flat washers, gasket and nut. Adjustments will need to be made to accommodate valves and other equipment.
- Bolt torque values based on lubricated bolts & nuts.

Torque Sequence - Table 1

Bolt torque sequence is shown below.




Bolt Kit Selection Guide

Bolt Hardware Kits Available For Connection of 2-Spears® Flanges Includes Bolts, Nuts & Flat Washers for Specified Flange Size

Order Gaskets & Bolt Kits Separately

- Pre-coated, Anti-seize Lubricated Bolts
- Available in Zinc Coated Steel, Type 316 Stainless Steel or Type 304 Stainless Steel



Flange Size	Bolts* Per Kit	Diameter (in.-TPI)	Length (in.)	Kit Part Number		
				Zinc	316 SS	304 SS
1/2	4	1/2 - 13	2	HK-005	HK1-005	HK2-005
3/4 & 1	4	1/2 - 13	2-1/4	HK-010	HK1-010	HK2-010
1-1/4 & 1-1/2	4	1/2 - 13	2-1/2	HK-015	HK1-015	HK2-015
2	4	5/8 - 11	3	HK-020	HK1-020	HK2-020
2-1/2	4	5/8 - 11	3-1/4	HK-025	HK1-025	HK2-025
3	4	5/8 - 11	3-1/2	HK-030	HK1-030	HK2-030
4	8	5/8 - 11	3-1/2	HK-040	HK1-040	HK2-040
6	8	3/4 - 10	4	HK-060	HK1-060	HK2-060
8	8	3/4 - 10	4-1/2	HK-080	HK1-080	HK2-080
10 & 12	12	7/8 - 9	6	HK-120	HK1-120	HK2-120

* Each Bolt Includes Nut & Two (2) Flat Washers

Made in the U.S.A.

Suitable for Oil-Free air handling to 25 psi, not for distribution of compressed air or gas
See Spears® Product Sourcebook for product offerings



Configuration Terminology

- Multi-Bolt Pattern Ring** - Bolt hole drilling accepts ANSI and Metric Flanges
- Socket** - Slip socket connection for solvent cement welding
- Spigot** - Pipe O.D. connection for solvent welding
- IPS** - Iron Pipe Size

Gaskets


Full faced, 1/8" thick elastomer gaskets with a Shore "A" Durometer of approximately 70 is recommended.

Gasket Selection Guide

Following Gasket Numbers Available from Spears®

Order Gaskets & Bolt Kits Separately

- 1/8" Full-Face design with ANSI Class 150 Bolt Patterns
- Pressure rated to 150 psi @ 73°F
- Available in Buna-N, EPDM, or FKM



Flange Size	Bolts Per Kit	Gasket Part Number		
		Buna-N	EPDM	FKM
1/2	4	GK1-005	GK2-005	GK3-005
3/4	4	GK1-007	GK2-007	GK3-007
1	4	GK1-010	GK2-010	GK3-010
1-1/4	4	GK1-012	GK2-012	GK3-012
1-1/2	4	GK1-015	GK2-015	GK3-015
2	4	GK1-020	GK2-020	GK3-020
2-1/2	4	GK1-025	GK2-025	GK3-025
3	4	GK1-030	GK2-030	GK3-030
4	8	GK1-040	GK2-040	GK3-040
6	8	GK1-060	GK2-060	GK3-060
8	8	GK1-080	GK2-080	GK3-080
10	12	GK1-100	GK2-100	GK3-100
12	12	GK1-120	GK2-120	GK3-120

CPVC Marine Flange Sample Engineering Specification

All EverTUFF™ CPVC marine flanges shall be produced by Spears® Manufacturing Company from CPVC materials, with a cell classification of 23447 in accordance with ASTM Standard D 1784. All injection-molded marine flanges shall be designed and manufactured to meet CL150 bolt pattern per ANSI Standard B16.5 and be certified by NSF International for use with potable water service. M851 and M854 series hubs shall accept ASTM IPS pipe. Rings shall be manufactured to accept bolt patterns in ANSI Class 150, B.S. 4504 PN10, B.S. 4504 PN16, B.S. 10 Table E for size 10". Metric Duetsche Industrie Norm (DIN) flange hubs shall accept 3" or 4" ASTM IPS Pipe. Rings shall be manufactured to DIN 8063-4 PN 10 and PN 16 bolt patterns. CPVC CL300 flanges shall accept ASTM IPS Pipe. CL300 rings shall be manufactured to the Class 300 bolt hole pattern from ANSI B16.5 and shall be pressure rated to 150psi @ 73° F.

Joining Method - Mechanical Grooved Couplings

In many installations where transition to metal pipe, or where disassembly is a prime factor, metallic grooved style couplings with gasket seal can be used to join CPVC pipe to alternate IPS size piping materials. In addition to the ease of disassembly, this type of connection also allows for a certain degree of angular adjustment and expansion/contraction. Special rolled-groove pipe can be joined, but easy to use molded Grooved Coupling Adapters then can be solvent cemented to plain end pipe are available for use with metallic grooved couplings.

Only flexible style metallic grooved couplings are recommended for use with plastic pipe. Rigid style couplings should not be used as these can provide a compressive/shear load to plastic pipe resulting in failure. Always check the compatibility of the grooved coupling gasket material with the intended application fluids.

•**NOTE** A gasket/joint lubricant is recommended to prevent pinching the gasket and to assist the seating and alignment processes during assembly of grooved couplings. Certain lubricants may contain a petroleum base or other chemicals, which will cause damage to the plastic pipe, gasket and adapter. Always verify the suitability for use of the selected lubricant with the lubricant manufacturer.



Installation

Outdoor Applications & Protection

CPVC marine piping systems must be protected from freezing. Many standard cold weather piping design and installation practices can be used to protect the system from freezing, such as use of pipe insulation, anti-freeze solutions, and heat trace tapes. The suitability and compatibility of these products for use with CPVC should be verified with product manufacturer prior to use.

Caution should be exercised in installing CPVC marine piping products in metal boxes or enclosures exposed to direct sunlight. Such enclosures can act as "ovens" that significantly increase the environmental temperatures over ambient air conditions, resulting in product damage and failure.

CPVC marine piping exposed to the direct sunlight (UV radiation) should be painted with a reflective, light colored acrylic or latex paint. Avoid dark colors, especially black. Heat absorption can exceed the heat handling capacity of the pipe and fitting material. Compatibility information regarding use with CPVC products should be confirmed with the paint manufacturer. Oil-based paints should not be used.

Hangers and Supports

Hanger Support Spacing

Support location and spacing depends on the pipe system operating temperature, and the location of any concentrated stress loads (i.e., valves, flanges, test equipment and any other heavy system components). Hangers must have at least 1/2" load-bearing surface free of any rough or sharp edges that could damage the pipe during use. Hangers also must not restrict linear movement of the system in order to allow thermal expansion and contraction from temperature changes.

Split ring pipe hangers and/or wrap around type brackets with adequate corrosion resistance can be used. Hangers should be smooth, free of burrs and provide at least 1/2" load-bearing surface.

Proper support spacing can be calculated similarly to that of metal systems by using simple and continuous beam calculations. This can be achieved using the maximum fiber stress of the material, or deflection based on the long term modulus of the material at the temperature selected as the limiting factors.

Hanger Selection

Hangers designed for metallic pipe can be used if they provide an adequate load-bearing surface, which is smooth and free of rough or sharp edges that could damage the pipe. Improper supports can generate excessive sag resulting in failure. Movement caused by thermal expansion/contraction and pressure fluctuations must be considered. Hangers and supports used must permit axial movement of the system, but not compress the pipe. Supplemental guides may be required in addition to hangers in order to maintain alignment and direct movement into in-line expansion joints.

Placement

Hangers should be installed within two feet of each side of a pipe joint; while changes in direction should be supported as close as possible to the fitting to reduce stress. Heavy system components such as valves, flanged assemblies, tees and other concentrated stress loads must be independently supported. Valves should additionally be adequately braced to prevent movement/stress loads from operational torque. Support of potential solids accumulation loads within the line should also be considered.

Precautions

Protective sleeves or pads used between the pipe and the hanger will distribute stress loads over a greater surface area, especially when using roller type hangers. Protective sleeves or pads should also be used when horizontal piping is resting on abrasive support structures. Do not allow piping to contact abrasive surfaces that could cause damage during axial movement. Avoid contact with heat producing sources.

Do not install plastic piping in close proximity to high temperature equipment without providing appropriate protection to prevent damage from distortion or expansion/contraction. Care should be taken to avoid over tightening of anchors, clamps or other support devices. This can distort or even fracture the piping. Vertical lines must be supported properly at intervals that will prevent excessive loading on the fitting at the lower end. Hangers and clamps suitable for this purpose include riser clamps or double bolt type clamps installed in such a manner that will allow for movement of the pipe due to thermal expansion and contraction.

Clamps and hangers used must not compress, distort, cut or abrade the piping. Common practice is to install clamps just below a coupling so that the shoulder of the coupling rests on the clamp. Fittings can be modified in the field to achieve this by cutting a coupling in two, just above the stop at the socket bottom, and then cutting this piece in half lengthwise to provide two halves which do not contain the stop. The two halves are then solvent cemented to the pipe at the proper location so that the shoulder of the modified coupling rests on the clamp. Riser clamps that utilize compression to support the pipe weight should not be used.

Anchor Guides

Anchors direct movement of the piping by providing restraint at key points such as long straight runs, at changes in direction of the system, and where expansion joints and other methods of thermal compensation are utilized. They may be used to control forces caused by expansion and contraction, generated by pressure surges, vibration, and other transient conditions. Guides are necessary to help direct this movement between anchors by allowing longitudinal movement while restricting lateral movement. Depending on the application and type, guides may or may not act as supports. Support guides should have the same load bearing surface and other requirements of hangers designed for the system. Guides must be rigidly attached to the structure to prevent lateral movement, but should not restrict longitudinal movement of the pipe through the guide. Anchors and guides must be engineered and installed without point loading the system.

Recommended Pipe Support Spacing

The following hanger support spacing recommendations are according to size, schedule, and operating temperatures. Do not clamp supports tightly - this restricts axial movement of the pipe. If short spacing is necessary, continuous supports may be more economical. These are considered conservative in nature and are based on straight runs of un-insulated lines with fluids with a specific gravity of 1.00 or less. These values do not consider concentrated weight loads or aggressive reagents.



Marine & Offshore Technical Installation

Support Spacing Adjustment for Fluids of Different Specific Gravity

Recommendations for CPVC marine piping support spacing in the following table are based on straight runs of uninsulated lines conveying fluids with specific gravities up to 1.0 (water). For specific gravities greater than 1.0, the spacing from the Support spacing tables should be multiplied by the following correction factors. System components such as valves, flanged assemblies, tees and other forms of concentrated loads must be independently supported.

Specific Gravity	1.0	1.1	1.2	1.4	1.6	2.0	2.5
Correction Factor	1.00	.98	.96	.93	.90	.85	.80

Temp (F)	1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"	4"	6"	8"	10"	12"
73	5-1/2	5-1/2	6	6-1/2	7	7	8	8	9	10	11	11-1/2	12-1/2
100	5	5-1/2	6	6	6-1/2	7	7-1/2	8	9	9-1/2	10-1/2	11	12-1/2
120	4-1/2	5	5-1/2	6	6	6-1/2	7-1/2	7-1/2	8-1/2	9	10	10-1/2	11
140	4-1/2	4-1/2	5	5-1/2	5-1/2	6	6-1/2	7	7-1/2		9	9-1/2	10-1/2
160	3	3	3-1/2	3-1/2	3-1/2	4	4-1/2	4-1/2	5	5-1/2	6	6-1/2	7-1/2
180	2-1/2	2-1/2	3	3	3-1/2	3-1/2	4	4	4-1/2	5	5-1/2	6	6-1/2

•NOTE This chart is based on continuous spans and for un-insulated line carrying fluids of specific gravity up to 1.00.

CPVC PIPE SUPPORT SPACING (ft.)

PIPE SIZE (in.)	SCHEDULE 40						SCHEDULE 80					
	73°F	100°F	120°F	140°F	160°F	180°F	73°F	100°F	120°F	140°F	160°F	180°F
1/2	5	4-1/2	4-1/2	4	2-1/2	2-1/2	5-1/2	5	4-1/2	4-1/2	3	2-1/2
3/4	5	5	4-1/2	4	2-1/2	2-1/2	5-1/2	5-1/2	5	4-1/2	3	2-1/2
1	5-1/2	5-1/2	5	4-1/2	3	2-1/2	6	6	5-1/2	5	3 1/2	3
1-1/4	5-1/2	5-1/2	5-1/2	5	3	3	6-1/2	6	6	5-1/2	3 1/2	3
1-1/2	6	6	5-1/2	5	3-1/2	3	7	6-1/2	6	5-1/2	3 1/2	3-1/2
2	6	6	5-1/2	5	3-1/2	3	7	7	6-1/2	6	4	3-1/2
2-1/2	7	7	6-1/2	6	4	3-1/2	8	7-1/2	7-1/2	6-1/2	4 1/2	4
3	7	7	7	6	4	3-1/2	8	8	7-1/2	7	4 1/2	4
4	7-1/2	7-1/2	7	6-1/2	4-1/2	4	8-1/2	9	8-1/2	7-1/2	5	4-1/2
6	8-1/2	8	7-1/2	7	5	4-1/2	10	9-1/2	9	8	5 1/2	5
8	9-1/2	9	8-1/2	7-1/2	5-1/2	5	11	10-1/2	10	9	6	5-1/2
10	10-1/2	10	9-1/2	8	6	5-1/2	11-1/2	11	10-1/2	9-1/2	6 1/2	6
12	11-1/2	10-1/2	10	8-1/2	6-1/2	6	12-1/2	12	11-1/2	10-1/2	7 1/2	6-1/2

•NOTE This chart based on continuous spans and for un-insulated line carrying fluids of specific gravity up to 1.00.